


English version:

Q. How Can I Set Up GC553 with OBS Studio

Install OBS Studio: <https://obsproject.com/>

1. Start OBS Studio→Source”+” Video Capture Device



2.Device→Live Gamer Ultra – Video

Notes:

When the video source is 1920 x 1080, please set the resolution and FPS exactly according to the source, the FPS will usually be 60, 59.94, 30 and 29.97

☆ Reference Note: The FPS of common devices is as follows


PlayStation 5: 59.94

PlayStation 4: 59.94


XBOX Series X | S: 59.94 iPhone 11 Pro Max: 59.94

iPad 11 Pro (3rd generation): 59.94


ROG Phone 5: 59.94




## Nintendo Switch: 60




## 3. Source" + " Audio Input Capture (Live Gamer Ultra-Audio)



## 4. Advanced Audio Properties




## 5. Audio Monitoring → Monitor and Output




6. How to solve image and sound out of sync problem in OBS or Streamlabs OBS  
Please adjust OBS settings:

1. Open OBS and right-click the "Mixer" gear icon.
2. Under "Advanced Audio Properties" >> "Video Capture Device" >> "Sync Offset" option, add value "-50 ~ -200" (ms)




(8) In case the image and sound out of sync problem in OBS or Streamlabs OBS in preview, you can try using different USB 3 ports, or try following the below setting:

Tick Use **Custom audio device**, and add **HDMI(Live Gamer Ultra-Audio)** in Audio Device.



Next, select **Monitor and Output** in Audio Monitoring in Video Capture device settings:




Notes: No need to add Audio Input device in Source column in OBS Studio.

中文版

Q.GC553 搭配 OBS 使用設定方式如下

A=請參照下方設定步驟

(1)開啟 OBS Studio→Source”+” Video Capture Device



2.Device→Live Gamer Ultra - Video

Notes:

當影像來源為 1920 x 1080 時，請完全按照來源設定解析度和 FPS，FPS 通常會有 60、59.94、30 及 29.97

☆ 附註：常見的 FPS 如下：


PlayStation 5: 59.94

PlayStation 4: 59.94


XBOX Series X | S: 59.94 iPhone 11 Pro Max: 59.94

iPad 11 Pro (3rd generation): 59.94


ROG Phone 5: 59.94




## Nintendo Switch: 60




## 3. Audio Input Capture (Live Gamer Ultra-Audio)



## 4. Advanced Audio Properties




## 5. Audio Monitoring→Monitor and Output




(7)如何解決 OBS 或 Streamlabs OBS 中的圖像和聲音不同步問題  
請調整 OBS 設置：

- 1、打開 OBS，右擊“Mixer”齒輪圖標。
- 2.在“高級音頻屬性”>>“視頻捕獲設備”>>“同步偏移”選項下，添加值“-50 ~ -200”（毫秒）




(8) 如果 OBS 或 Streamlabs OBS 在預覽中出現圖像和聲音不同步的問題，您可以嘗試使用不同的 USB 3 端口，或嘗試按照以下設置：

勾選使用自定義音頻設備，並在原本視訊擷取設備中添加 HDMI(Live Gamer Ultra-Audio)。



接下來，在 Video Capture 設備設置中的 Audio Monitoring 中選擇 Monitor and Output：



注意：OBS Studio 的 Source 欄中無需添加 Audio Input 設備。