


Model name: GC553 & GC551G2

**Question:**



**How can I enable VRR on my Xbox Series X and PlayStation®5?**

**Xbox Series X :**

To turn on VRR on Xbox Series X, go to General> TV & display options




and then Video modes.



Make sure **Allow variable refresh rate** is checked.


Notes:

If you would like to capture or record high frame rate than 60 with GC553/GC551G2 on XBox, you need to untick Allow 4K & Allow HDR10.




## PlayStation®5

1. Head to the PS5 Home
2. Select Settings, then choose Screen and Video



3. Select Video Output., then Choose VRR and set it to Automatic.



4. VRR will now be enabled on PS5 for supported titles.

